

QuickFill™ Electric Air Pump

Model AP609 12V  72 W

READ AND FOLLOW ALL INSTRUCTIONS BEFORE USING THIS PRODUCT


WARNING

- Household use only. Use only under competent supervision.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Risk of injury:** do not direct air stream at face or body.
- **Risk of electric shock:** do not expose to rain or stand on a wet surface when using air pump. Store indoors.
- **Risk of burning:** do not use for more than 5 minutes at a time in “high volume-low pressure” setting and no more than 5 minutes at a time in “low volume-high pressure” setting.
- Do not operate for more than 5 minutes at a time. Unplug and let cool at least 15 minutes.
- The appliance is only to be used with the power supply unit provided with the appliance. It must only be supplied at safety extra low voltage corresponding to the marking on the appliance.

FOLLOW THESE RULES AND ALL INSTRUCTIONS TO AVOID PROPERTY DAMAGE, ELECTRIC SHOCK, BURNS OR OTHER INJURY.

SAVE THESE INSTRUCTIONS


NAMES OF PARTS



NOTE: Drawings for illustration purpose only. Actual product may vary. Not to scale.

Operating instructions:

1. Connect the air hose to the air pump (Front to inflate, Back to deflate).
2. Select the power source: 12V DC cigarette lighter outlet or 220 - 240V AC household power outlet. Connect the DC or AC plug to the power connector.



3. Select the desired nozzle size.
4. For faster inflation press “-” (high volume-low pressure air flow) to inflate soft articles such as, airbeds or inflatable toys.
5. Turn the switch to “=” (low volume-high pressure air flow) to inflate articles that require firmness or rigidity such as, athletic balls or fishing boat.

NOTE: Always start with “-” high volume-low pressure setting for faster inflation and then turn the switch to “=” low volume-high pressure for firmness if necessary. Maximum pressure: 0.083MPa (0.83bar).

6. Inflate article. **NOTE: To prevent bursting, do not over inflate.**
7. Switch OFF by pressing “O”.

Storage:

No specific maintenance is required for the air pump. Air pump has no user serviceable parts.

Return pump, hose, nozzles and plugs to packing carton, and store indoors when not in use.

©2023 Intex Marketing Ltd. - Intex Development Co. Ltd. - Intex Recreation Corp. All rights reserved/Tous droits réservés/Todos los derechos reservados/Alle Rechte vorbehalten. Printed in China/Imprimé en Chine/Impreso en China/Gedruckt in China.

®™ Trademarks used in some countries of the world under license from®™ Marques utilisées dans certains pays sous licence de/Marcas registradas utilizadas en algunos países del mundo bajo licencia de/Warenzeichen verwendet in einigen Ländern der Welt in Lizenz von/Intex Marketing Ltd. to/à/a/ an Intex Development Co. Ltd., Hong Kong & Intex Recreation Corp., P.O. Box 1440, Long Beach, CA 90801 - Distributed in the European Union by Distribúe dans l'Union Européenne par/Distribuido en la unión Europea por/Vetrib in der Eurosäsischen Union durch/Intex Trading B.V., Eltenseweg 46, 4706 PB Roosendaal - The Netherlands • Distributed in the UK by Unitex Service (UK) Limited, 21 Holborn Viaduct, London EC1A 2DY, UK. www.intexcorp.com

INTEX®

SAVE THESE INSTRUCTIONS