


INTEX®

Relax! The airbed is not leaking air

The first few times you use the airbed; it may seem as if it is losing air. However, this is not the case.

At first the material of the airbed stretches to its correct shape. The airbed will not lose air but there will be more room for the air.



We recommend that you fill the airbed with air at least 2 or 3 times and let it rest for a few hours each time. You will notice that the difference will be less.

If the problem has not been resolved, please [contact local service centre for further assistance.](#)